



canopy material is .015 plastic such as Sig Aeroplastic
 cut test canopy from heavy paper first to confirm fit
 then cut canopy from plastic sheet along bold line.
 cut canopy from line B to C on fold line AB

lightly score material with Exacto knife on fold line from point A to B
 gently fold canopy sides down along AB line as shown in section A
 fold front windscreen down on line DE as shown in section B
 glue windscreen to side panels with Ca using drops from pin dipped in
 Ca puddle. Reinforce joint with clear canopy glue on inside after set
 attach canopy with thin Ca drops and then fillet with clear canopy glue
 apply drops of glue to cut line at back to seal

Canopy Fabrication

scale 1:1